

midi LOGGER HV GL2000 is Problem Solving Tool!

Common cause failures

- Power Source
- Motor (Bearing, Coil, Shaft bushes)
- Secular Change

GL2000 will tell you the cause!

- Power Supply Voltage (3-Phase), Voltage DIPS, Surge noise, Over-current, Temperature, Vibration, Sound, Rotation
- Time-series monitoring will help you detect the failure sign
- Various trigger function

midi LOGGER HV GL2000

Key-functions for Maintenance Use

Portable & Handy Design

- External dimension: Approx. 260 x 161 x85 mm
- Weight : Approx. 1.7kg
- Optional battery
- Protect cover

The instrument is in compliance with JIS Vibration Test Method for Automobile Type 1 Class A. (Vibration durability test: 5m/s²)

Large 7.0 inch TFT Display / Stand-alone Operation (PC-less) On-site

Real time statistical calculation

Deg.	1004			
VALUE	Max	Min	P-P	Ave
1. 731	+ E. 009	- 2.0(8	+ 4.019	+ 0.601
0.003	+ 3.001	- 2.067	+ 4.014	+ 0.001
0.001	+ 0.013	- 0.053	+ 0.036	- 0.001
0.004	+ 0.014	- 0.021	+ 0.035	+ 0.001
			100	
	1.731 0 0.003 0 0.001 0	1. 731 1 + z. 604 0. 000 1 + z. 604 0. 001 1 + 0. 603	1. 731 1 + 2.004 - 2.010 0.003 1 + 3.007 - 2.007 0.001 1 + 0.013 - 0.023	1, 731 , + 2 600 - 2 010 + 4 010 0, 003 1 + 2 607 - 2 007 + 4 010 0, 001 7 + 0 672 - 0 027 + 0 030 0, 004 1 + 0 014 - 0 021 + 0 031

Search Level




Data replay while capturing



CAT III Compatible

3-Phase 3-Wire 380V 50Hz measurement



High Speed(1MS/s), High Resolution(16-bit)





RMS(Root Mean Square) Measurement

Measure in RMS

Detecting AC Voltage fluctuation in RMS


Fast and micro variation: (Noise from power surge,






Triggered in case of Voltage DIPS (Voltage drop & momentary stop)

Block Segmentation of Build-in RAM




- Overwrite (Continuous)
- New data will be saved over old data. Auto-back-up
- RAM data will be auto-copied to Internal Flash Memory.



RPM Measurement

Individual sampling speed setting on Pulse

switching surge, lightning surge)



Detailed RPM trend can be monitored (Especially for slow RPM)

- Due to the possibility of equipment or PC failure, the data files on the instrument will not be guaranteed to be held on the memory. Please make a backup of data whenever possible to avoid data loss.
 Brand names and product names listed in this brochure are the trademarks or registered trademarks of their respective owners.
 Items mentioned are subject to change without notice. For more information about product, please check the web site or contact your local representative.



- For using equipment in correctly and safely . Before using it, please read the user manual and then please use it properly in accordance with the description. . To avoid malfunction or an electric shock by current leakage or voltage, please ensure a ground connection and use according to the specification.

GRAPHTE

Graphtec America, Inc.

17462 Armstrong Avenue Irvine, CA 92614 www.graphtecamerica.com/instrumnets T: 949.860.4186 E: inst.sales@graphtecamerica.com

